



# READ THIS NOW

## PQS 201 Mk II Unpacking Instructions

## 1. UNPACKING YOUR LOUDSPEAKERS

**NOTE:** When lifting the loudspeakers out of the packing, hold them by the upper or lower plates. Do not lift them by the DDD support pillars (see figure 2) as this may damage the driver.

The DDD drivers may be protected with clear film or cardboard covers. We recommend that these be left in place until the loudspeakers have been placed in their final location, so as to guard against accidental damage during handling.

The two loudspeakers are packed in one carton. Before opening the carton, please inspect it for damage. If you see any damage to the carton, please contact the supplying audio dealer immediately and provide them with a full description of the damage. Do not attempt to unpack the loudspeakers until you have spoken with the dealer and have been advised how to proceed.

Please retain all of the packing as you will need this should it be necessary in the future to ship the loudspeakers. The use of any other packing may result in the loudspeakers sustaining damage in transit. Such damage is not covered by the warranty. Should you require replacement packing, please contact your German Physiks dealer, the national distributor or the factory directly.




Figure 1. PQS-201 Mk II Shipping Carton

To unpack the loudspeakers please follow the instructions below:

1. Unscrew and remove the two screw caps on each side of the carton top cover – item A in figure 1.
2. Remove the carton top cover by carefully pulling it over the four screws.
3. Remove the foam packing piece from the top of the main body of the carton - item B in figure 1.
4. Unscrew and remove the two screw caps on each side of the carton lower tray – item C in figure 1.
5. Lift off the main body of the carton – item B in figure 1. This may be folded flat for easy storage.
6. Lift the loudspeakers off the lower packing tray by holding them around the cabinets or top plates. Do not lift the loudspeakers by the DDD driver support pillars.
7. Remove any clear film from around the loudspeakers taking care not to scratch the finish. Do **not** use a knife.

Please confirm that the carton contains the following items:

Item	Quantity	Description
1	2	PQS-201 Mk II Loudspeakers
2	1	PQS-201 Mk II User Manual
3	2	Cleaning Cloths

If any items are missing, or show signs of damage, please contact the supplying audio dealer immediately.

## 2. THE PRINCIPLE FEATURES OF THE PQS-201 Mk II



Figure 2. The Principle Features of the PQS-201 Mk II